724 8179



 Ref
 SSSASRTD

 Date
 01/10/97

 Issue No
 2

 Page No
 1 of 4

# ROCOL SAFE STEP™ SELF ADHESIVE SLIP RESISTANT SURFACES Tackwise | Data & Application Instructions

# **Technical Data & Application Instructions**

### Description

ROCOL Safe Step™ Self Adhesive Slip Resistant Surfaces comprise of a mineral coated plastic film treated on one side with a pressure sensitive adhesive, protected by a removable liner.

**ROCOL Safe Step™ Self Adhesive Slip Resistant Surfaces** provide a hard wearing, slip resistant surface, for application to concrete, masonry, wood, ceramic tiles and metal etc., both inside and out.

## **Technical Data (Typical)**

Unit Size: Available in rolls of widths between 25 -

150mm and in various sizes as pre-cut

Treads & Tiles.

Colour: Black

Mineral particles
Particle size:
Hardness:
Silicon Carbide
180 - 300 microns
mohs scale 9

Bonding Medium: Copolymer Adhesive Weight of Product: 800 - 850 g/sq. mtr Break Strength (ASTM D882): 6500 lbs/sq inch

26 lbs/inch of width

Shear Resistance (PSTCTM): 2 lbs/sq inch after 500+ hours

Removal of film: Maximum 164 N/m Adhesive thickness: 100± 10 microns

Application temperature:

Above 5°C

Heat Resistance:

-20 to 90°C

Chemical Resistance: Good resistance to water, motor oil (Incidental contact) hydraulic fluid, detergent, petrol, diesel

TRRL Slip Resistance Values:

 Dry:
 89

 Wet:
 45

 Oily:
 35

 Shelf Life:
 2 years

Suitable Application: Internal & External

 Ref
 SSSASRTD

 Date
 01/10/97

 Issue No
 2

 Page No
 2 of 4



#### **Surface Preparation**

All surfaces must be clean, dry and free from oil, grease, petrol, waxes and loosely adhered material prior to application of ROCOL Safe Step™ Self Adhesive Slip Resistant Surfaces.

Metal:

Rust and paint should be removed to ensure proper

adhesion between the primer and the surface.

Wood:

Should be smooth, sound and dust free.

Concrete and Masonry:

Must be sound and non - crumbling, with no dust or grit present. Very hard ultra smooth surfaces may need to be treated to provide a suitable key and all concrete should be

at least 28 days old.

#### **Application**

Priming - to achieve the best possible bond. It is recommended that the surface is first treated with **ROCOL Strong Bond** before applying the self adhesive surfaces. After priming, a drying time of at least 20 minutes should be allowed prior to laying the self adhesive surfaces.

Laying - remove the backing paper and accurately position the adhesive surface. Start laying at one end and using firm pressure work towards the other end, without trapping air bubbles. A hard rubber or wooden roller may be of assistance should there be any trapped air bubbles these can be punctured and pressed down.

Once the **ROCOL Safe Step™ Self Adhesive Slip Resistant Surfaces** are in place, they are immediately ready for use.

#### Applying ROCOL Safe Step™ Self Adhesive Slip Resistant Surfaces

There are some surfaces to which it may be difficult to apply ROCOL Safe Step™ Self Adhesive Slip Resistant Surfaces or some that you may be unsure as to the compatibility - for example Alkyd or Epoxy resin coatings may have "waxy" ingredients which resist adhesives bonding them, some concretes may contain "anti-freeze" or silicone additives which may repel adhesives.

 Ref
 SSSASRTD

 Date
 01/10/97

 Issue No
 2

 Page No
 3 of 4



As there are so may variables it is impossible to legislate for every eventuality but as a rule of thumb, IF YOU ARE UNSURE, TEST IT!

#### **A Standard Test**

Routine would be to apply a piece of **ROCOL Safe Step™ Self Adhesive Slip Resistant Surfaces** to a clean, dry surface in a normal traffic area and leave for a minimum of 7 days - if after this time it is still securely applied, the surface should be satisfactorily compatible.

Porous surfaces - untreated concrete, bare wood, unglazed quarry tiles should be prepared as above and the surface primed with **ROCOL Strong Bond**. When applying to quarry tiles do not apply over grout. Apply **ROCOL Safe Step™ Self Adhesive Tiles** over quarry tile surfaces only.

In areas where any liquid or moisture is normally present, eg. external applications, prepare the surface with **ROCOL Strong Bond** and always apply **ROCOL Edge Sealer** (see separate Technical Data Sheets).

#### **Edge Fixing**

To prevent the possible ingress of fluids around the edges, it is advisable to seal these with **ROCOL Edge Sealer** before use.

Using the tapered nozzles provided, apply a bead of edge sealer around the edges making sure that edge contact is made with both the substrate and the slip resistant self adhesive surface. Leave to dry for a minimum of 6 hours before putting into service.

Do not apply ROCOL Safe Step™ Self Adhesive Slip Resistant Surfaces to plasticised or vinyl floor coverings.

#### **Surface Maintenance**

It is essential that ROCOL Safe Step<sup>TM</sup> Self Adhesive Slip Resistant Surfaces are regularly cleaned to maximise anti-slip performance. Under normal conditions periodically sweeping with a stiff brush is all that should be required. For heavily soiled surfaces the use of a water based biodegradable detergent cleaner may be used in conjunction with a fibre bristled brush. After cleaning, thoroughly rinse with clean water and allow to dry before use.

 Ref
 SSSASRTD

 Date
 01/10/97

 Issue No
 2

 Page No
 4 of 4



## **Health & Safety**

Refer to Health & Safety Data Sheet before use. If further copies are required please contact ROCOL Site Safety Systems, ROCOL House, Swillington, LEEDS LS26 8BS Tel: 0113 232 2800 or dial our Fax-Back facility on 0113 232 2772.